


## Quick Entry to Operation Data Option

Press **ESC** **ESC** "Function General" will be displayed

If "Function Cascade Control" is displayed, press **↓** or **↑**

Until "Function General" screen. Then press **◀**

Press **↓** or **↑** until Access Level screen is visible then press **◀**



Press **◀** current access level will flash in display

Enter access codes for desired level

**↑** **↓** **ESC** **◀** Access level 2

**↓** **ESC** **◀** **ESC** Access level 3

Press **ESC** **ESC** to exit into desired level

Press **↓** or **↑** until Cascade Control screen is visible then press **◀**

